


SCAFFOLDING

MOBILE TOWER ASSEMBLY INSTRUCTIONS

These instructions have been abbreviated. If the user is unsure about any part of the scaffold setup process, they should contact Presco Hire on 0800 44 10 44 for further assistance. Reverse the steps below for dismantle.




STEP 1:

- Take a scaffold side and lock wheel brakes
- Attach 2 horizontal braces (yellow) to the inside, above the lowest transom.




STEP 2:

- Take other scaffold side and lock wheel brakes
- Attach horizontal braces (yellow) to the inside, to the opposite side. Use screwjacks to level.




STEP 3:

- Attach plan brace (red) diagonally. The suggested position is just above the wheels.
- Note:** 0.7m wide scaffolds don't require this.




STEP 4:

- Install 4 diagonal braces (silver) from bottom transom to third transom up. These should be as close as practical to the outside. Level in each direction using adjustable screwjacks.
- Note:** 0.7m wide scaffolds only require 2, 1 each side, running in opposite directions.



STEP 5:

- Add additional height as required.
- Add 4 diagonal braces (silver) per 3-4 transoms
- Add 2 diagonal braces (silver) per 1-2 transoms
- Each brace should be attached to the top transom of the frame below.



STEP 6:


- When the desired height is reached, ensure 2 transoms extend above for the handrails.
- Install platforms and 4 horizontal braces (yellow) to the inside as handrails and midrails. Install ladder and toeboards.

YOUR ONE SUPPLIER FOR EQUIPMENT HIRE, NATIONWIDE.

Service area: Nationwide | **Branches:** New Plymouth & Hawera | **Phone:** 0800 44 10 44 | **Email:** hire@presco.co.nz

SCAFFOLDING

MOBILE TOWER ASSEMBLY INSTRUCTIONS



TOEBOARD INSTALLATION

Toeboards are made up of a 4 piece system, 2 ends and 2 sides. It is important that the toeboards are fitted the correct way around. Two important notes are:

- The nuts holding the fittings are placed on the outside
- Install the end boards with the male part of the hinge facing up so that the female part of the hinge (on the side boards) locates downwards into position.

LADDER INSTALLATION

Ladders must ALWAYS be installed inside the tower. Where possible, it is best practice to fit the ladder as high as possible (fig 3.) but in the circumstances when this would lead to the base of the ladder being too high, one of the other options may be used.

- Figure 1 - Level with the platform
- Figure 2 - One transom above the platform
- Figure 3 - Two transoms above the platform



Fig.1



Fig.2



Fig.3

SAFETY TIPS:

- AS/NZS 4576:1995 should be referred to for safe work practices.
- For towers that could be exposed to wind loads or have a height to base ratio greater than 3:1, advice is available by phoning Presco Hire on 0800 44 10 44.
- Always ensure you understand and can comply with the regulations that apply to the erection and use of scaffolding in the area that you intend on using this equipment.
- The ladder can extend up to 2 transoms above the platform level, but must be at least up to the same level as the platform.
- Depending on desired height, ensure you have at least 900mm above your platforms as your handrail.
- **DO NOT STAND, SIT OR LEAN ON MIDRAILS OR HANDRAILS.**

YOUR ONE SUPPLIER FOR EQUIPMENT HIRE, NATIONWIDE.

Service area: Nationwide | **Branches:** New Plymouth & Hawera | **Phone:** 0800 44 10 44 | **Email:** hire@presco.co.nz